

# LED TRUSS WARMER EFFECTS OPERATION GUIDE

= DOWN POSITION (ON)

= UP POSITION (OFF)

Thank you for buying our LED light product series. We strongly suggest that you READ these instructions before operation. This device has been tested and has passed high quality control procedures before delivery to ensure the best performance. Please DO FOLLOW these steps to prevent possible malfunction (including when using a remote control device)

## 1. DMX-512 controlled:

You can use a DMX controller to control the LED lighting effects by simply setting the appropriate "dip" switches.

### 4 DMX CHANNELS:

CHANNEL	VALUE	FUNCTION
1	0-255	RED
2	0-255	GREEN
3	0-255	BLUE
4	6-160	DIMMER
	161-255	STROBING / SPEED

### Synchronization method 1:

For "Master & Slave" synchronization when using a DMX controller, set all unit's dip switch 1 to down (on)

<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	2	3	4	5	6	7	8	9	10	11	12

NOTE: If one or more units are not reacting correctly when synchronizing please move "dimmer and strobing" channel up and down on the DMX controller to solve this problem.

### Synchronization method 2:

For "four channel" synchronization when using a DMX controller...

First Unit: dip switch 1 set down (on)

<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	2	3	4	5	6	7	8	9	10	11	12

Second Unit: dip switch 1 and 3 set down (on)

<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	2	3	4	5	6	7	8	9	10	11	12

Third Unit: dip switch 1 and 4 set down (on)

<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	2	3	4	5	6	7	8	9	10	11	12

etc...

## 2. Built-in 8 effects dip switch operation:

Please see the "LED DIP SWITCH TABLE" page for your reference.

## Safety Precautions

- 1) Light-safety information: Light Emission Class 2, DO NOT LOOK INTO LIGHT
- 2) If the unit is not in use, please turn off
- 3) Do not use or immediately turn off if the unit becomes damaged, especially the cord or light enclosure.
- 4) Keep away from children
- 5) Unit is to be used only at the correct rated voltage and frequency noted
- 6) Do not carry or unplug by use of the cord